


REVISIONS			
LTR	DESCRIPTION	DATE	APP'D

**FOUR FUNCTION AIR SWITCH
PUMP/BLOWER SCHEMATIC**



NOTES:

1. ALL WIRING TO BE DONE PER LOCAL AND NATIONAL CODE.
2. USE GFCI AND CIRCUIT BREAKER WHERE APPLICABLE.

SWITCHING SEQUENCE

	PUSH 1	PUSH 2	PUSH 3	PUSH 4
PUMP	OFF	ON	ON	OFF
BLOWER	OFF	OFF	ON	ON

PRESAIR LLC
1009 W.BOSTON POST ROAD
MAMARONECK, NY 10543

DEFAULT TOLERANCES ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED	.XX ±1/64 .XXX ±.005 ≤ ±0.5*	SCALE NONE	MATERIAL
DRAWN BY T.I.	SHEET 1 OF 1	ISSUED 10-08-13	TITLE SWITCH SCHEMATIC
		DWG NO. MSA325A/B	REV A